

1. Introduction

1.1 Overview

Thank you for choosing our all-in-one energy storage system. This manual will assist you in becoming familiar with this product. Please keep this manual available at any time. And read the manual and other related documents before performing any operation and take into account the connection requirements by your local grid utility. This manual cannot include complete information about the photovoltaic (PV) system. All descriptions in the manual are for guidance only.

This manual describes the installation process, maintenance, technical data and safety instructions for the following models:

Apollo-3KLP1G01/3K6LP1G01/4KLP1G01/4K6LP1G01/5KLP1G01/6KLP1G01/6KLP1G01-MX

Apollo-Hybrid all in one ESS series

3K/3K6/4K/4K6/5K/6K:Rated power is 3000W/3600W/4000W/4500W/5000W/6000W


L:Low voltage

P1:Single phase

G01:Generation 01

MX: The number of battery module. M4 means 4 battery modules. It can be 2-5 in this model. This manual is intended for qualified persons and inverter owners. All activities described in the document may only be carried out by specially trained personnel in compliance with standards, wiring rules and the requirements of local grid authorities or companies. Moreover, they must also understand basic safety precautions and with the knowledge of how to deal with the dangers and risks associated with installing, repairing and using electrical devices and batteries.

Before all the steps, we would like to remove the protect plate of the inverter on both left and right side. Then we will see many ports.



* 11. Fuse(Non professionals are not allowed to open this cover)

If the fuse is burnt out, please open the cover and replace it

Inverter Wire Box and Connection Points

Number	NAME	DESCRIPTION
1	WiFi module	For installing the WiFi module
2	LCD display	Display the status and basic operation
3	BMS port	Conduit for Battery communication (Inverter site)
4	PV port	Conduit for PV conductors should be connected here
5	PV Switch	Switch on and switch off the PV connection to inverter
6	Battery communication	Conduit for Battery communication (Battery site)
7	Battery LED	Showing battery SOC
8	Batter Power	Click to power on the battery
9	Battery Breaker	Pull to connector/disconnect battery with inverter
10	Battery Power Port Positive site (+)	Conduit for Battery power connection
11	Battery Fuse	Easy window to replace the fuse. Non-professionals are not allowed to open this cover
12	Battery grounding port	Grounding, connect to the ground cable
13	Battery switch	Conduit for setting the communication address
14	Battery Power Port Negative site (-)	Conduit for Battery power connection
15	AC Terminal	Conduit for AC,backup loads and smart meter should be connected here
16	DRMS port	Ready for DRMS controller connection
17	PARA port	Conduit for system parallel
18	COM port	Conduit for smart meter communication
19	Inverter Grounding port	Grounding, connect to the ground cable

1.2 Product Features

- Compact design saves your space and installation cost.
- Flexible inverter power from 3kw ~ 36kw (maximum 6 systems in parallel).
- Flexible Storage Capacity with modular batteries from 5kwh ~ 20kwh. (maximum 6 systems in parallel will expand to 120kwh)
- Safer and longer working life with modular LFP battery.
- Complete protection against Over Voltage, Over Temperature, and Overload.
- Programmable supply priority for battery or grid.
- Auto restart while AC is recovering.
- Hybrid inverter maximize solar power and minimize grid energy usage.
- 100% output in off-grid mode.
- With power limit function, prevent excess power overflow to the grid.
- All in one design save the installation time and space.
- Using hybrid inverters and modular batteries.
- Smart settable three stages MPPT charging for optimized battery performance.
- Real-time Remote Control via APP and website.
- Peak balancing, Time setting and other grid services.

1.3 Data Sheet

Apollo-5KLP1G01-MX Series Data sheet						
Model	Apollo-3KLP1G01-M1	Apollo-3KLP1G01-M2	Apollo-3K6LP1G01-M1	Apollo-3K6LP1G01-M2	Apollo-4KLP1G01-M1	Apollo-4KLP1G01-M2
System Specification						
Nominal Output Power	3000VA/3000W	3600VA/3600W	3600VA/3600W	4000VA/4000W		
AC Output Frequency and Voltage	50/60Hz;L/N/PE 220/230Va.c					
Grid Type	Single Phase					
Energy Range	5.12kWh	10.24kWh	5.12kWh	10.24kWh	5.12kWh	10.24kWh
Max. Charging/Discharging Current	100A					
Battery Operating Voltage	44.8V~57.6V					
Battery Type	LiFePO4					
IP Rating of Enclosure	IP21					
System Certification	VDE-AR-N 4105; G99/1; EN50549-1; CEI 0-21; AS 4777.2					
Warranty[1]	5 Years(For the Inverter);10 Years(For the battery)					
Inverter Technical Specification						
Max. PV Input Power	3900W	4700W	4700W	5200W		
Max. PV Input Current	15A/15A					
Rated PV Input Voltage	90V~550V					
Start Up DC Voltage	130V					
MPPT Voltage Range	100V ~ 500V					
Max. PV Short-circuit Current	18A/18A					
No. of MPP Tracker	2/1					
Peak Power (off grid)	2 time of rated power, 0.2s					
Power Factor	0.8leading to 0.8lagging					
DC injection current (mA)	THD<3% (Linear load<2%)					
AC Output Voltage	230Va.c					
AC Output Frequency	50/60Hz					
AC Output Rated Current	13Aa.c	15.6Aa.c	15.6Aa.c	17.4Aa.c		
Max. AC Output Current	40Aa.c					
AC Output Rated Active Power	3000W	3600W	3600W	4000W		
AC Output Rated Apparent Power	3000VA	3600VA	3600VA	4000VA		
AC Output Power Factor	0.8 Leading To 0.8 Lagging					
Display	LCD+LED					
Operating Temperature Range	-20°C~65°C,>45°C Derating					
Relative Humidity	15% ~ 85% (No Condensing)					

Dimension(Wx Dx H,mm)	600x450x640mm					
Weight Appr.	58.8kg					
Communication with BMS	CAN/RS485					
Grid Regulation	VDE-AR-N 4105; G99/1; CE: EN50549-1, NRS 097-2-1; CEI 0-21; AS 4777.2					
Safety Regulation	IEC 62109-1/2, IEC 62040-1					
EMC	EN61000-6-1, EN61000-6-3					
Max. efficiency	97.5%					
Euro efficiency	96.7%	96.7%	96.7%	96.8%		
MPPT efficiency	99.9%					
Battery Technical Specification						
Nominal Voltage	51.2V					
Battery Module Energy	5.12kWh	10.24kWh	5.12kWh	10.24kWh	5.12kWh	10.24kWh
Scalability	Max.4pcs,Max.capacity of 20.48kWh					
Battery Module Dimension(WxDxHmm)	600*450*180	600*450*360	600*450*180	600*450*360	600*450*180	600*450*360
Battery Base Dimension (WxDxHmm)	590*440*120mm					
Battery Module Weight Appr.	46kg	92kg	46kg	92kg	46kg	92kg
Charging Temperature Range	0°C~55°C					
Discharging Temperature Range	-20°C~55°C					
Cycle Life	≥6,000 Cycles[Test conditions: 0.2C Charging/Discharging @25°C, 80% DOD.]					
Battery Module Certification	UN38.3.CE					
[1]Conditions apply, refer to FelicityESS Warranty policy						

Apollo-5KLP1G01-MX Series Data sheet





















Model	Apollo-4K6LP1G01-M1	Apollo-4K6LP1G01-M2	Apollo-5KLP1G01-M1	Apollo-5KLP1G01-M2	Apollo-6KLP1G01-M1	Apollo-6KLP1G01-M2
System Specification						
Nominal Output Power	4600VA/4600W	5000VA/5000W	6000VA/6000W	6000VA/6000W	6000VA/6000W	6000VA/6000W
AC Output Frequency and Voltage	50/60Hz; L/N/PE 220/230Va.c					
Grid Type	Single Phase					
Energy Range	5.12kWh	10.24kWh	10.24kWh	5.12kWh	10.24kWh	10.24kWh
Max. Charging/Discharging Current	100A		120A			
Battery Operating Voltage	44.8V~57.6V					
Battery Type	LiFePO4					
IP Rating of Enclosure	IP21					
System Certification	VDE-AR-N 4105; G99/1; EN50549-1; CEI 0-21; AS 4777.2					
Warranty[1]	5 Years(For the Inverter); 10 Years(For the battery)					
Inverter Technical Specification						
Max. PV Input Power	6000W	6500W	7800W			
Max. PV Input Current	15A/15 A					
Rated PV Input Voltage	90V~550V					
Start Up DC Voltage	130V					
MPPT Voltage Range	100V ~ 500V					
Max. PV Short-circuit Current	18A/18A					
No. of MPPT Tracker	2/1					
Peak Power (off grid)	2 time of rated power, 0.2s					
Power Factor	0.8leading to 0.8lagging					
DC injection current (mA)	THD<3% (L:linear load<2%)					
AC Output Voltage	230Va.c					
AC Output Frequency	50/60Hz					
AC Output Rated Current	20Aa.c	21.7Aa.c	26Aa.c			
Max. AC Output Current	40Aa.c					
AC Output Rated Active Power	4600W	5000W	6000W			
AC Output Rated Apparent Power	4600VA	5000VA	6000VA			
AC Output Power Factor	0.8 Leading To 0.8 Lagging					
Display	LCD+LED					
Operating Temperature Range	-20°C~55°C, >45°C Derating					
Relative Humidity	15% ~ 85% (No Condensing)					
Dimension(Wx D x H,mm)	600x450x640mm					
Weight Appr.	58.8kg					

Communication with BMS	CAN/RS485					
Grid Regulation	VDE-AR-N 4105; G99/1; CE: EN50549-1, NRS 097-2-1; CEI 0-21; AS 4777.2					
Safety Regulation	IEC 62109-1/2, IEC 62040-1					
EMC	EN61000-6-1, EN61000-6-3					
Max. efficiency	97.6%					
Euro efficiency	97.0%					
MPPT efficiency	99.9%					
Battery Technical Specification						
Nominal Voltage	51.2V					
Battery Module Energy	5.12kWh	10.24kWh	5.12kWh	10.24kWh	5.12kWh	10.24kWh
Scalability	Max. 4pcs, Max capacity of 20.48kWh					
Battery Module Dimension(WxDxH,mm)	600*450*180	600*450*180	600*450*360	600*450*180	600*450*360	600*450*360
Battery Base Dimension (WxDxH,mm)	590*440*120mm					
Battery Module Weight Appr.	46kg	92kg	46kg	92kg	46kg	92kg
Charging Temperature Range	0°C~55°C					
Discharging Temperature Range	-20°C~55°C					
Cycle Life	≥6,000 Cycles(Test conditions: 0.2C Charging/ Discharging @25°C, 80% DOD.)					
Battery Module Certification	UN38.3 CE					
[1]Conditions apply, refer to FelicityESS Warranty policy						



1.4 Package list

Check the equipment before installation. Please make sure nothing is damaged in the package. You should have received the items in the following package. If anything is missing, please contact your local FelicityESS distributor.

Apollo-5KLP1G01-MX





				
				
				
				

LUX-X-48100LMG01



1.5 Installation tools

Check the equipment before installation. Please make sure nothing is damaged in the package. You should have received the items in the following package. If anything is missing, please contact your local Solis distributor.



2. Safety and warning

2.1 Safety introductions

- This chapter contains important safety and operating instructions. Please read and keep this manual for future reference.
- Before using the inverter, please read the instructions and warning signs of the battery and corresponding sections in the instruction manual.
- Do not disassemble the inverter. If you need maintenance or repair, take it to a professional service center.
- Improper reassembly may result in electric shock or fire.
- To reduce risk of electric shock, disconnect all wires before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- Caution: Only qualified personnel can install this device with battery.
- Never charge a frozen battery.

- For optimum operation of this inverter, please follow required specification to select appropriate cable size. It is very important to correctly operate this inverter. Be very cautious when working with metal tools on or around batteries. Dropping a tool may cause a spark or short circuit in batteries or other electrical parts, even cause an explosion.
- Please strictly follow installation procedure when you want to disconnect AC or DC terminals.
- Please refer to "Installation" section of this manual for the details.
- Grounding instructions - this inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- Never cause AC output and DC input short circuited. Do not connect to the mains when DC input short circuits.

2.2 Symbols

The following types of safety instructions and general information will appear in this document as described below:

Symbols	Name	Instruction
	Danger	Serious physical injury or even death may occur if not follow the relative requirements
	Warning	Physical injury or damage to the devices may occur if not follow the relative requirements
	Electrostatic sensitive	Damage may occur if not follow the relative requirements
	Hot surface	Sides of the device may become hot. Do not touch.
	Earth terminal	The inverter must be reliably grounded.
	Caution	Ensure that DC and AC side circuit breakers have been disconnected and wait at least 5 minutes before wiring and checking.
NOTE	Note	The procedures taken for ensuring proper operation.
CE	CE mark	The inverter complies with the CE directive.
	EU WEEE mark	Product should not be disposed as household waste.

2.3 Notice for Use

The ESS system has been constructed according to the applicable safety and technical guidelines, use the ESS system in installations that meet the following specifications only:

- Permanent installation is required.
- The electrical installation must be compliant with all local and national regulations & standards.
- The ESS must be installed according to the instructions stated in this manual section 3.4.
- The ESS must be installed according to technical specifications.

2.4 Notice for Disposal


- This product shall not be disposed of with household waste.
- It must be segregated and brought to an appropriate disposal facility to ensure proper recycling.
- This is to be done in order to avoid negative impacts on the environment and human health.
- Local waste management rules shall be observed and respected.

3. Installation

3.1 Install environment


When selecting a location for the product, the following criteria should be considered:

1. Sun and Temperature: Exposure to direct sunlight may cause output power derating due to overheating. It is recommended to avoid installing the machine in direct sunlight. The working temperature is -25°C~ 60°C, but the ideal temperature should be 15~25°C.
2. Humidity: High humidity environment can lead to a decrease in the insulation performance of electronic components, causing malfunction of electrical equipment. In addition, high humidity can also lead to rusting of metal parts, affecting the life of the equipment. So, we suggest to choose a dry place for installation. At least, it should be non-condensing.




MAX RH: 100%
(Non condensing)

3. Air: Do not install in small, closed rooms where air cannot freely circulate. Well-ventilated environment also helps to keep a good temperature.
4. Loading: Max load bearing capacity of the wall should higher than 4 times of machine weight.
5. Clearance and space: Ensure there is sufficient space for heat-releasing. Generally, it requires 300mm for each site.



6. Surrounding: Please ensure that there are no flammable or explosive materials located near the system, and make the area clean and accessible for installation.
7. Protect from bad weather: The installation of ESS should be protected under shelter from direct sunlight, snow laying, rain exposure, lightning and etc.



8. Avoid living area: Do not install in a living area where the prolonged presence of people or animals is expected. Depending on where the system is installed (for example: the type of surface around the machine, the general properties of the room, etc.) and the quality of the electricity supply, the sound level from the inverter can be quite high.

WARNING: Risk of fire

Despite careful construction, electrical devices can cause fires.

- Do not install the inverter in areas containing highly flammable materials or gases.
- Do not install the inverter in potentially explosive atmospheres.
- The mounting structure where the inverter is installed must be fireproof.




CAUTION: Hot Surface

- The temperature of the inverter heat-sink can reach 75°C



Note: Install it at eye level in order to read the LCD display easier.


Overview wiring system



3.2 Product Handling

Please review the instruction below for handling the inverter:

1. The red circles below denote cutouts on the product. Push in the cutouts to form handles for moving the inverter and battery.



2. Two people are required to remove the inverter from the shipping box. Use the handles integrated into the heat sink to remove the inverter from the carton.




The machine is heavy please be careful when moving


3. When setting the machine down, do it slowly and gently. This ensures that the internal components and the outer chassis from damage.

3.3 Mounting


Location selecting already talked in [Install environment]. Please mount the unit tightly on a solid or smooth surface. Open the packages and middle cover kit, then take out the subjects. The size is as follow.




STEP 1: Remove the cover
Remove the waterproof cover from both sides of the inverter and set it aside.




STEP 2: Install the wheels for the base bracket
Fix the 4 casters on the base bracket with M6x16 screws as the picture shows.



Step 3: Mark and drill holes
Use wall mounted positioning cardboard to mark the holes layer by layer. Drill holes according to the position marked on the wall. (the hole diameter is 10mm, drilling depth is 60mm)




Step4: Assemble Mounting Bracket and stack together
Assemble the wall mounting bracket with screws on the inverter and batteries as shown below. Then stack and place the products, with a base on the bottom layer, batteries on the middle layer, and inverter on the top layer




There are positioning pins between layers for guidance, please do not use force to damage them

Step5: Tighten the connection between layers with hexagonal screws for both sides.




Step6 □ After all the wiring finish, fix the system on the wall with screws and expand nails. Fix the cover back to the ports for protection.




3.4 Ground Cable Installation

An external ground cable shall be connected to ground plate on right side first, before connecting other cables. This helps prevent electric shocking and improving electromagnetic interference resistance. For system with single inverter, it is only necessary to connect the ground cable. For a multi-inverter system, all ground cables of the inverter need to be connected to the ground copper bar to ensure equipotential connection.

Step 1. Prepare OT terminals: M5. Use wire strippers to crimp the lug to the terminal with a suitable length. Then thread the wire into the terminal and press it with a crimper.



Step 2. Connect the OT terminal with ground cable to the right side of inverter with screw. The torque is 2N.m.



3.5 PV Cable Installation


- 1) For safety, please install a separately DC breaker between inverter and PV strings.
- 2) Block the PV with an opaque material and turn off the DC breaker.
- 3) The total short-circuit current of PV string must not exceed inverter's max DC current.
- 4) The minimum isolation resistance to ground of the PV string must exceed 19.33kΩ in case to prevent shock hazard.
- 5) PV string could not connect to earth/grounding conductor.
- 6) Use the right PV plugs in the accessory box.
- 7) Make sure polarity is correct. The inverter will not function properly if any PV polarity is reversed.

Step 1 Assembling the PV Connectors


- Select a suitable DC cable and strip the wires out by 6-8mm. Please refer to the table below for specific specifications.

Cable type	Wire Size	Cross-Section	Strip Cable length
Industry generic PV cable	12 AWG	4~6mm ²	6-8mm

- Assemble the cable ends with the crimping pliers.
- Lead the cable through the cable gland and insert the crimp contact into the insulator until it snaps into place and a "click" sound is heard. Gently pull the cable backward to ensure firm connection.
- Tighten the cable gland and the insulator.




Step 2. Verify polarity
Measure PV voltage of DC input with multimeter, verify DC input cable polarity.



Step 3: Connecting the PV cables to the inverter

- Connect the PV connectors to the corresponding terminals until a “click” sound is heard.
- Seal the unused PV terminals with the terminal caps.



3.6 Battery Cable Installation



•The polarity of battery cannot be connected reversely, otherwise the inverter could be damaged.



DANGER

Before installing the battery cables, be sure that the battery is turned off. Use a multimeter to verify that the battery voltage is 0Vdc before proceeding. Consult the battery product manual for instructions on how to turn it off.




NOTE


Before connecting the battery, please carefully read the product manual of the battery and perform the installation exactly as the battery manufacturer specifies in the manual

Take the prepared battery copper bar and BMS communication cable from package. In section mounting, we already stacked the inverter and battery together.


Step 1. Connect the grounding wire for the battery



Step 2. Please open the lid latch upwards, rotate the lid and tear off the lid cover. Use screws to connect the copper bar with the ports in same pole. Positive pole connected from bottom to top and the negative pole connected from top to bottom. (The direction already printed on the battery)



Step 3. Connect [BMS] to [LINK1], [LINK 0] to [LINK 0] with battery communication cables.




Step 4. Adjust each battery pack dialer from left to right according to the diagram below (from top to bottom).

ON DP		1	2	3	4
1PCS	1,5 ON				
2PCS	1,5 ON	2,5 ON			
3PCS	1,5 ON	2 ON	1,2,5 ON		
4PCS	1,5 ON	2 ON	1,2 ON	3,5 ON	

DIP SWITCH	
1-4	Communication Address
5	Termination Resistor

After installation, it will look like the picture shown below. This ESS support maximum 4 battery in parallel. If you need more battery bank work in parallel, connect the battery in same way.




Notes:

- The battery (+) and (-) cables shall only be connected to the inverter BAT terminals.
 - For safe operation and compliance, a two-pole DC circuit breaker with overcurrent protection should be installed between the inverter and the battery.
 - Please be careful of any electric shock or chemical hazards. For batteries without a built-in DC breaker, make sure that an external DC breaker (≥125A) connected.
- The BMS Pin definition are as follow. If you need to make another one, please make sure the right wire sequence, otherwise will cause failure.

Table :Detailed Pin Function Of COM Port On All-in-one

Position	Function	Note
1	485_A2	RS485-2 For Meter
2	485_B2	
3	485_A3	
4	485_B3	
5	485_B3	
6	485_A3	
7	RY_4	Dry Signal
8	RY_5	



Picture	PIN	Description
	1	Trigger-GND
	2	Trigger-VCC
	3	CANL-PCS
	4	CANH-PCS
	5	RS485-B
	6	RS485-A
	7	CANL
	8	CANH

Pin function of LUX-X-48100LMG01 battery

The LED shows the SOC of each battery.

100%	75%	50%	25%	Flashing SOC < 10%

3.7 Grid and Backup Wiring

Before connecting to grid, please install a separate AC breaker between inverter and grid. The absence of AC breaker on back-up side will lead to inverter damage if an electrical short circuit happens on back-up side. The requirements of on-grid AC breaker are shown as below.

INVERTER MODEL	AC BREAKER SPECIFICATION
Apollo-3KLP1G01/3K6LP1G01 /4KLP1G01/4K6LP1G01 /5KLP1G01/6KLP1G01-MX	40A/230V,2P


There are two terminal blocks with "Grid" and "Load" markings. Please do not disconnect input and output connectors.

	Description
Backup load connection	10AWG, Cross section 4 mm ²
Grid connection wire	10AWG, Cross section 6 mm ²
Strip length	10mm


Please follow below steps to implement Grid and Back up Load port connection:

STEP 1. Before making Grid, load port connection, be sure to turn off AC breaker or disconnecter first.


STEP 2. Strip the wires by 10mm length, unscrew the bolts, cross the wires through the water proof cap.




STEP 3. Insert the wires according to the correct polarities indicated on the terminal block. (L1M1 for backup load, L2N2 for grid) Then lock the cable by press the bar until hear the click sound. Make sure the connection is complete.



STEP 4. Insert the wire terminal inside the AC cover until here click sound, then tighten the nut




STEP 5. Connect the combined AC cables with inverter with AC PORT. Then tighten the screw in the AC terminal



3.8 Meter & CT Connection

The Smart Meter with CT in product box is compulsory for this ESS installation, which used to detect grid voltage and current direction and magnitude.




The Smart Meter with CT in product box is compulsory for this ESS installation, which used to detect grid voltage and current direction and magnitude.




CAUTION:
Make sure the AC cable is totally isolated from AC power before connecting the smart meter or CT.

Note:

- Make sure AC cable is totally isolated from AC power before connecting Smart Meter.
 - One Smart Meter can only be used for one hybrid inverter.
 - Normally the smart meter should be placed in or near the grid distribution box right after the billing meter.
 - Please use the smart meter communication cable in the package.
- Please strip the wires and install the meter as the figure. It is recommended to use 0.5A or 3A for the fuse in the connection diagram.
- Please strip the wires and install the meter as the figure(1 to L, 4 to N). It is recommended to use 0.5A or 3A for the fuse in the connection diagram




The Meter communication line is included in the package. Please connect the COM PORT and the RS485 on the meter.




If you need further operation condition of inverter via RS485 communication, please See Table follow.

Position	Function	Note
1	/	/
2	/	/
3	+VCC	Power Supply
4	COM-GND	
5	RS485-B1	Lithium Battery Communication
6	RS485-A1	
7	CANL1	
8	CANH1	



Please install the CT on the Live Wire (L) at the system grid connection point and the arrow on the CT needs to point to the grid direction.



The Meter communication line is included in the package. Please connect the COM PORT and the RS485 on the meter.


STATUS	OFF	ON	Blinking
Run (Green)	The instrument is not running	/	The instrument is running normally
Com (Red)	The instrument is not communicating	/	The instrument is in communication status
R-P (Red)	Positive power	Negative power	/
(Red)	/	Negative value indicator lamp	/

3.9 DRMS connection (optional)


In Australia and New Zealand, the AS/NZS 4777.2:2020 required inverter needs to support Demand Response Mode (DRM). FelicityESS inverter support remote shutdown function to remotely control the inverter to power on and off through logic signals. The DRM port is provided with an RJ45 terminal and its Pin5 and Pin6 can be used for remote shutdown function. Our inverter has integrated a terminal block for connecting to a Demand Response Enabling Device (DRED)

Wiring Connection Procedure:

Step 1: Unscrew the nut from DRMS port.




Step 2: Plug out the RJ45 terminal and dismantle the resistor on it. Plug the resistor out, leave the RJ45 terminal for next step.




NOTE

• The RJ45 terminal in the inverter has the same function as DRED. Please leave it in the inverter if no external device is connected.

Step 3 Pass the RJ45 cable through the steel plate and connect the DRED cable to the RJ45 terminal. Pin port definition is shown in Figure.




*DRM Connector Pin Definition



Mode	
DRM0	Operation disconnect device.
DRM1	Do not consume power
DRM2	Do not consume more than 50% of rated power
DRM3	Do not consume more than 75% of rated power AND Source reactive power if capable
DRM4	Increase power consumption (subject to constraints from other active DRMs)
DRM5	Do not generate power
DRM6	Do not generate more than 50% of rated power
DRM7	Do not generate more than 75% of rated power AND absorb reactive power if capable
DRM8	Increase power generation (subject to constraints from other active DRMs)

NOTE Demand response modes of Table 3, 1 are as described in AS/NZS 4755.3 series of Standards.

Step 4 Plug the wires into the DRMS port on the inverter. Fasten the swivel nut and connect the other end to the DRED. (DRED is not provided by FELICITYESS)




3.10 WIFI module installation and Monitoring

The ESS can be remotely monitored by APP and website via WIFI or 4G. If there is no WIFI, using 4G signal may result in communication fees charged by local telecom.

Step 1: Remove the waterproof lid from the Wi-Fi/4G terminal (On the top side of the inverter)
Step 2: Insert the Wi-Fi stick into the communication port. Slightly shake it by hand to determine whether it is installed firmly.

Step 3: Build the connection between the inverter and router. Please refer to section 4.3 to configure the WLAN with APP.



The ESS can be remotely monitored by APP and website via WIFI or 4G. If there is no WIFI, using 4G signal may result in communication fees charged by local telecom.

Step 1: Remove the waterproof lid from the Wi-Fi/4G terminal (On the top side of the inverter)
Step 2: Insert the Wi-Fi stick into the communication port. Slightly shake it by hand to determine whether it is installed firmly.

Step 3: Build the connection between the inverter and router. Please refer to section 4.3 to configure the WLAN with APP.

	Indicates load level by 1-25%,26-50%,51-75% and 76-100%
	Indicates the PV panels.
	Indicates PV MPPT is working.
METER	Indicates communication is built between inverter and meter
Mute Operation	
	Indicates unit alarm is disabled.

The base information will be switched by pressing [UP] or [DOWN]

Example	Information
	Utility frequency 50Hz Inverter output 230V Battery DOC 100% Load level 50% 1 PV MPPT working, with meter.
	PV2 power is 3.00KW Inverter output 230V Battery DOC 100% Load level 50% 1 PV MPPT working, No meter
	Battery voltage 50.0V Output 2.00KW Battery DOC 100% Load level 50% 1 PV MPPT working, No meter Alarm disabled

	Battery voltage 54.0V Battery discharging current 40A No utility, no PV, Battery DOC 100% Load level 50%
	Total load power 2.00KW
	CPU software version is 1100

4.3 Setup with APP

This is an intelligent cloud platform, enables users to achieve information management of photovoltaic plants. It equips users with real-time monitoring, plant, and device management, as well as remote control and intelligent alarm functionalities. You can log in account at any time through a computer, IOS or Android to achieve real-time display and remote control.

Monitoring web: <https://shine.felicityess.com>

APP: Search [FSOLAR] on Google Play store or Apple App Store. OR scan the following QR code.

